

# BIO-DEX®



## FILTER CLEANER M2000

FOR CARTRIDGE, DIATOMITE AND SAND SWIMMING POOL FILTERS

- Effectively and quickly removes scale, rust, oils, grease and most soils from filters
- Non-carcinogenic
- Improves filtration
- Safe to equipment
- Environmentally friendly

### HELPFUL SUGGESTION:

For improved filtration results, water circulation and water clarity, add *Bio-Dex Clearex 500 Water Clarifier* to pool water as per directions on *Clearex 500* label.

## FILTER CLEANER M2000

### CAUTION - CORROSIVE

Keep out of reach of children and away from food. Do not take internally, may be fatal if swallowed. Can cause chemical burns. Do not breath vapors or fumes. Do not get in eyes. Avoid prolonged contact on skin. Wear protective eye goggles or face shield and wear protective rubber gloves on hands when handling this product. If spilled on clothing, remove at once and wash clothing before reuse. Do not mix with other chemicals.

### Use Only As Directed

### FIRST AID

**EYE CONTACT:** Flush eyes for 15 minutes with running water, lifting eyelids frequently for complete irrigation. See a physician immediately.

**SKIN CONTACT:** Wash immediately with running water. If irritation develops see a physician immediately.

**IF SWALLOWED:** Drink large quantities of chalk solution, whiteing or milk. See a physician immediately. Never give any liquids to an unconscious person.

### DIRECTIONS FOR USE

- SAND AND DIATOMITE FILTERS**
1. Remove suction type cleaner hose from skimmer temporarily.
  2. While filter system is backwashing to waste, pour 10 oz. of Bio-Dex Filter Cleaner M2000 through skimmer.
  3. Allow filter to continue backwashing until water is clear and clean.
  4. Return filters to normal filtration cycle.
  5. For Diatomite Filters, be sure to add the appropriate amount of Diatomite Filter media after backwashing.

### CARTRIDGE FILTERS

1. Remove cartridges, rinse off with clear water and place into solution of one quart Bio-Dex Filter Cleaner M2000 per 10 gallons of clean water. Use plastic type container.
2. Allow cartridges to soak in solution for 4 hours (longer if extremely dirty). When cleaning is completed, remove cartridges from cleaning solution, rinse off with clean water and return to filter for normal filtration operation.

**CAUTION - CORROSIVE**  
**KEEP OUT OF REACH OF CHILDREN**

Ordering Information:  
(623) 582-2400 • (800) 617-3477  
E-mail: [bio-dex@bio-dex.com](mailto:bio-dex@bio-dex.com) • Website: [www.bio-dex.com](http://www.bio-dex.com)

**THANK YOU FOR CHOOSING BIO-DEX!**