

BIO-DEX

PLASTER WHITE 'N BRITE

FOR ACID WASHING SWIMMING POOLS

Bio-Dex Plaster White 'n Brite liquid concentrate offers a new concept and dimension creating the latest state-of-the-art for acid washing swimming pools.

- ENVIRONMENTALLY SAFE
- 100% BIO-DEGRADABLE
- NO ETCHING OF PLASTER
- NO ACID FUMES
- NO SCRUBBING
- NON-CORROSIVE
- NON-TOXIC
- FAST ACTING
- USER FRIENDLY

**BIO-DEX FAST-ACTING PLASTER WHITE 'N BRITE
EFFECTIVELY REMOVES CALCIUM, COPPER AND
OTHER STUBBORN METAL STAINS**

PLASTER WHITE 'N BRITE

BIO-DEX Plaster White 'n Brite imparts superior cleaning and removal of calcium deposits, copper, and other metal stains, dirt, oil, and grease stains from pool plaster. When used as directed, BIO-DEX Plaster White 'n Brite eliminates acid fumes, thickens the acid/water solution for better "cling" to pool plaster without etching plaster.

Never acid wash a plastered pool if plaster is cracked, chipped, or "rebar" is exposed, or if pieces of plaster have broken free from pool walls or from any plastered areas.

DIRECTIONS FOR USE

STEP 1: Dilute one gallon swimming pool muriatic acid into the desired amount of water. A good "starter" mix would be one gallon acid added into two gallons water. Use a 5 gallon or larger clean plastic pail.

STEP 2: Add 8 oz. BIO-DEX Plaster White 'n Brite to the diluted acid solution. Stir solution slowly for one minute to thicken, using a wood or plastic type pole. You are now ready to acid wash pool.

STEP 3: Using a small plastic pail, pour the mixed solution along the tile line and allow solution to run down plaster and dwell for 4 to 5 minutes. Hose off. Usually brushing is not necessary, but optional.

If foaming is a problem (it rarely is), use BIO-DEX SPA FOAM STOP. It is concentrated and economical to use and is compatible with the BIO-DEX Plaster White 'n Brite solution. For severely stained pools, you may use a dilution of 2 gallons muriatic acid added into 3 gallons water and then add 16 oz. BIO-DEX Plaster White 'n Brite. When used as directed BIO-DEX Plaster White 'n Brite solution cleans without etching and leaves plaster smooth and beautifully white.

NOTICE

Always add acid to water, never add water to acid.

CAUTION

Use eye goggles and rubber gloves when using acid or acid solutions. Harmful if swallowed. Do not take internally. Avoid contact with skin and eyes. In case of contact wash with plenty of water for 15 minutes and for eyes call a physician. Remove any contaminated clothing and wash before reuse. Keep away from food. If swallowed do not induce vomiting. Drink large quantities of fluids. Call a physician immediately.



**DO YOU NEED
EXTREME
CLEAN?
Add Aquadex 50
Stain Off to the mix!**

Ordering Information:

(623) 582-2400 • (800) 617-3477

E-mail: bio-dex@bio-dex.com • Website: www.bio-dex.com

THANK YOU FOR CHOOSING BIO-DEX!